



MODEL 8905A
67-0907 SHEET 2 OF 2
REV.10 - 6/04

PARTS LIST FOR 8905A

ITEM	QTY	P/N	A*	B*	DESCRIPTION	ITEM	QTY	P/N	A*	B*	DESCRIPTION
01	2	62-1014			Screw, Flathead, #8-32x3/8	35	1	61-2214B			Wear Plate
02	1	61-2370			Window Holder	36	1	61-2149B	1		Gasket
03	1	61-2229A			Window Glass	37	2	2-62-0432			Lockwasher #6
04	1	66-0304	1		O-Ring, Fluoroelast. #127	38	1	61-2351			Mounting Plate
05	1	61-2413			Drain Plug	39	1	61-6324			Gas Ballast Valve Assembly
06	1	61-2158A	1		O-Ring, Fluoroelast. #110	40	1	61-9282A	1		O-Ring, Fluoroelast. #011
07	1	61-2355			Oil Case	41	1	61-9479A	1		Drip Pad
08	1	61-2130A			O-Ring, Fluoroelast. #115	42	1	61-2358			Intake Adapter
09	1	61-2372			Filler Plug	44	1	61-2159A	1		O-Ring, Fluoroelast. #116
10	8	2-00-6712			Screw, Sockethead, #10-32x3/4	45	3	2-00-6708			Screw, Sockethead, #10-32x1/2
11	22	2-62-0793			Lock Washer #10	46	1	61-2316			Motor Adapter Plate
12	3	62-0003			Screw, Sockethead, #10-32x3	47	2	4-21-5010			Dowel Pin, 3/16"x5/8"
13	1	61-2417			End Plate	48	2	41-2693			Coupling Body
15	4	2-69-6108			Lock Washer #8	49	4	2-00-6716			Screw, Sockethead, #10-32x1
16	1	61-2415			Baffle Assembly	50	1	41-2694	1		Coupling Rubber
17	2	61-2128A	2		O-Ring, Fluoroelast. #145	52	1	61-2377			Handle
18	2	4-21-3006			Dowel Pin, 1/8"x3/8"	53	2	2-61-1165			Washer 1/4
19	1	61-2416			Stator	54	2	2-01-6112			Screw, Sockethead, 1/4-20x3/4
20	5	2-10-2605			Screw, Roundhead, #8-32x5/16	55	1	61-2039C			Motor Assembly 1/4 H.P. (115V,60Hz)
21	1	2-68-5632			Washer #8	55	1	61-2318			Motor Assembly 1/4 H.P. (230V,60Hz)
22	1	61-2017A			Exhaust Valve Bracket Assembly	55	1	61-9813			Motor 1/4 H.P. (100-120/200-240V)
23	2	61-2119A	2		Valve Spring	56	4	61-2123A	4		Rubber Bumper
24	2	61-2118A	2		Valve	57	1	61-2271C			Base
27	1	61-1123A	1		Intake Valve	58	4	2-00-6812			Screw, Sockethead, #10-32x5/8
28	1	61-1128A	1		Backer Valve	61	1	61-2139A	1		Disc Assembly, Isolator Valve
29	2	41-2988	2		Lip Seal	62	1	61-2216A			Plunger
30	1	61-2177B			Rotor	63	1	61-2155A	1		O-Ring, Fluoroelast. #020
31	2	61-2179A			Exhaust Vane	64	1	61-2212A			Adapter, Isolator Valve
32	2	61-2178A			Intake Vane	65	2	2-00-6410			Screw, Sockethead, #6-32x5/8
34	3	61-2157A	2		O-Ring, Fluoroelast. #007	66	1	61-2308			ISO Operator Assembly w/O-Ring

A*: MAJOR REPAIR KIT CAT # N/A
B*: MINOR REPAIR KIT CAT # 8905K-02